





3337



Liste de pièces
Lista de Piezas
Parts List

A




Pos	Part No.	Description
<u>AVAILABLE PARTS</u>		
2	68009208	CAPS
4	416121501	SET SCREW (M4x8 A)
5	416122201	SET SCREW (M4x10 B)
6	416554101	BOBBIN WINDER
7	68013188	SET SCREW (9/64x4 L=18)
8	416126301	NUT (9/64x40 t=3)
9	68003756	BACK COVER
10	416148101	BOBBIN WINDER THREAD GUIDE ADJUSTING
11	416185401	SET SCREW (M4x10 A)
13	68003763	STITCH LENGTH DIAL
14	68003559	REVERSE BUTTON
15	68001430	SET WASHER
16	68003576	THREAD GUIDE CPL.
17	416681501	SET SCREW (M3x8.5)
18	416804501	THREAD GUIDE
19	68003577	SPOOL PIN BASE
21	68003578	HANDLE

NOT AVAILABLE PARTS

1	68010964	FRONT COVER FOR 3337
3	416145101	ARM TOP COVER THREAD GUIDE PLATE
12	68010965	SELECTOR DIAL FOR 3337
20	68010961	NEEDLE PLATE COVER

B



Pos	Part No.	Description
-----	----------	-------------


AVAILABLE PARTS

#1	68003595	SEWING TABLE BODY CPL.
1	68010960	DIAL TENSION KNOB
3	68003757	FACE PLATE
4	412423701	THREAD CUTTER
5	416116701	CS-RING (CSTW-5)
6	416185401	SET SCREW (M4x10 A)
7	68003581	BED COVER
8	416121101	SET SCREW (M4x10 B)
9	68003591	FREE ARM FOOT BASE FOR 3337
10	68003263	FREE ARM BASE CUSHION
11	416185701	SET SCREW (M6x10)
12	416122201	SET SCREW (M4x10 B)
13	416526001	ADJUSTMENT FREE ARM BASE CUSHION RUBBER
16	68003595	SEWING TABLE BODY. SEE #1
17	68003595	SEWING TABLE BODY COVER. SEE #1
18	68003595	SEWING TABLE PLATE. SEE #1
19	416681501	SET SCREW (M3x8.5)
20	68003595	FELT. SEE #1

NOT AVAILABLE PARTS

2		
14	68010963	DIAL TENSION SUPPORTER PLATE COVER
15	68010962	BH LEVER BUTTON FOR 3337
21	68010965	HAND WHEEL

C



Pos	Part No.	Description
-----	----------	-------------


AVAILABLE PARTS

#1	416765401	THREAD TAKE UP LEVER CPL.
1	416427701	BELT
2	416154401	SPRING
3	416154601	ADJUSTMENT SCREW
4	416526001	ADJUSTMENT FREE ARM BASE CUSHION RUBBER
5	416799901	ARM SHAFT
10	416156301	ARM SHAFT BUSING
11	416156501	ARM SHAFT COLLAR
13	416680201	ARM SHAFT SPROCKET
14	416117601	PIN (3x18)
16	416727301	BELT
18	416122401	SET SCREW (M4x4 C)
20	416307201	CLUTCH SLEEVE
21	270 D5A0573003	ARM SHAFT CLUTCH ANNULUS SPRING
22	416680801	ARM SHAFT DRIVER BELT PULLEY
24	416680701	SPRING PIN (3x30)
26	416121501	SET SCREW (M4x8 A)
27	416765401	THREAD TAKE UP LEVER CPL. (SEE #1)
28	416765401	THREAD TAKE UP LEVER SUPPORTER (SEE #1)
29	416116001	E-RING (ETW-3)
30	416765401	THREAD TAKE UP LEVER SUPPORTER SHAFT (SEE #1)
31	416765401	ARM SHAFT BALANCE PIN CPL. (SEE #1)

NOT AVAILABLE PARTS

6	416566401	ARM SHAFT BALANCE
7	416122101	SET SCREW (M4x6 C)
8	416117701	PIN (3.5x24)
9	416125101	ENDURE ATTRITION WASHER (10.2x15x0.5)
12	270 004250203	SET SCREW (M5x5 C)
15	416116501	E-RING (ETW-9)
17	68013256	ARM SHAFT WORM CPL.
19	270 003043028	PIN (3x28)
23	416542901	E-RING (ETW-8)
25	416161701	ARM SHAFT BUSHING HOLDER PLATE
32	416524701	ENDURE ATTRITION WASHER (6.2x12x0.25)
33	270 H13093003	SET WASHER

D




Pos	Part No.	Description
-----	----------	-------------

AVAILABLE PARTS

3	416187301	BH FEED CRANK SPRING FOR 3337
6	416116001	E-RING (ETW-3)
11	416119201	SET SCREW (M3x6 A)

NOT AVAILABLE PARTS

#1	68004499	PATTERN CAM CONTACT CPL. FOR 3337
1	416604901	WASHER (6.7x12xt0.5) FOR 3337
2	416545201	BH FEED CRANK FOR 3337
4	416545601	BH ADJUSTING CRANK FOR 3337
5	416122701	SET SCREW (M4x0.7 L12) FOR 3337
7	416597501	SS CAM CONTACT
8	416166401	SS CAM CONTACT SPRING
9		
10		
12	416598001	ZIGZAG CAM CONTACT SUPPORTER SHAFT
13	416544901	ZIGZAG RELEASE PLATE
14	68015308	NUT (M4x0.7)
15	416185501	SET SCREW (M4x0.7 L9)
16	416545001	ZIGZAG RELEASE PLATE SPRING
17		ZIGZAG CAM CONTACT SUPPORTER FOR 3337 (INCLUDED IN #1)
18	416183801	E-RING (ETW-5)
19	416545301	SPRING PEDESTAL
20	416517801	ZIGZAG CAM CONTACT SPRING
21	416545501	ZIGZAG CAM CONTACT
22		
23		
24	416597301	SS CAM CONTACT SUPPORTER CPL.
25	416597401	FEED ROCK SHAFT



Pos	Part No.	Description
-----	----------	-------------



AVAILABLE PARTS

3	68003182	FEED REGULATOR CAM
5	416228101	WASHER (8.2x14x0.5)
6	416427901	SS CAM
8	416151801	PATTERN CAM SHAFT COLLAR
9	416122401	SET SCREW (M4x4 C)
10	68003183	PATTERN CAM FOR 3337
13	416121501	SET SCREW (M4x8 A)
14	416195301	PATTERN FIX SPRING PLATE
15	416226601	SET SCREW (M4x5 B)

NOT AVAILABLE PARTS

1	416596801	PATTERN CAM CONTACT PLATE (FRONT)
2	416543701	PATTERN CAM CONTACT PLATE (BACK)
4	416116401	E-RING (ETW-6)
7	416543801	PATTERN CAM SHAFT
11	416546501	FEED REGULATOR FIX PLATE
12	416524501	SET SCREW (M4x4 B)
16	416543901	BH FEED REGULATOR CAM FOR 3337
17	416544001	BH CLUTCH CONTACT A FOR 3337
18	416229201	BH CLUTCH SHAFT FOR 3337
19	416544101	BH CLUTCH LEVER FOR 3337
20	416544201	BH CLUTCH CONTACT B FOR 3337
21	416229601	BH CLUTCH SPRING PLATE FOR 3337
22	416544301	BH CAM FOR 3337
23	416544401	BH CONTACT FOR 3337
24	416544501	BH SLIDE BLOCK R FOR 3337
25	416544601	BH CONTACT SPRING PLATE FOR 3337
26	416544701	BH SLIDE BLOCK L FOR 3337
27	416544801	STRAIGHT STITCH CAM FOR 3337

F



Pos	Part No.	Description
-----	----------	-------------


AVAILABLE PARTS

8	416119201	SET SCREW (M3x6 A)
10	416121501	SET SCREW (M4x8 A)

NOT AVAILABLE PARTS

1		
2	416599501	PATTERN SELECTOR CAM SHAFT FOR 3337
3	416183901	PIN (2.5x16)
4	416185201	SET SCREW (M4x10)
5	416546301	FEED REGULATING CRANK SPRING
6	416605301	PATTERN SELECTOR CAM FOR 3337
7	416116401	E-RING (ETW-6)
9	416546401	PATTERN CAM CONTACT SUPPORTER SHAFT


G



Pos	Part No.	Description
<u>AVAILABLE PARTS</u>		
2	416700601	BOBBIN WINDER CRANK CPL.
4	270 K6A0573003	BOBBIN WINDER CRANK SPRING
7	416802801	REVERSE LEVER
8	416802801	REVERSE ROD
9	416155001	AUTO THREADED LEVER SPRING
10	416116001	E-RING (ETW-3)
12	416198701	THREAD GUIDE
14	416124101	WASHER (4.2x8x0.8)
15	416162601	DIAL TENSION SPRING
16	416116701	CS-RING (CSTW-5)
17	416121701	SET SCREW (M4x15 B)
18	416121901	SET SCREW (M4x6)
21	416807201	DIAL TENSION SUPPORTER PLATE CPL.
27	416153801	DIAL TENSION REGULATOR
31	416116101	E-RING (ETW-4)

NOT AVAILABLE PARTS

1	416603101	BOBBIN WINDER FRAME PLATE CPL.
3	416116301	E-RING (ETW-5)
5	416121201	SET SCREW (M4x6 B)
6	416527201	TENSION LEVER REGULATING PLATE
11	416716301	SET SCREW
13	68013222	SET SCREW (M4x0.7 L42)
19	416151701	DIAL TENSION GUIDE SPRING TUBE
20	416117501	PIN (3x10)
22	416735101	DIAL TENSION WAFT PLATE
23	416153601	DIAL TENSION DISC (1)
24	416146301	DIAL TENSION DISC
25	416526801	DIAL TENSION SPRING REGULATOR
26	416772201	DIAL TENSION SPRING
28	416716901	DIAL TENSION SPRING PLATE
29	416126001	WASHER (WW-5)
30	416124501	WASHER (5.2x10x0.5)




Pos	Part No.	Description
-----	----------	-------------

AVAILABLE PARTS

2	416173601	NEEDLE BAR
8	416150801	NEEDLE BAR BRACKET (1)
9	416150801	NEEDLE BAR BRACKET (2)
10	416122401	SET SCREW (M4x4 C)
11	416235801	NEEDLE BAR CRANK ROD
14	416116101	E-RING (ETW-4)
15	416245301	NEEDLE CLAMP CPL.
16	68013226	PRESSER BAR REGULATING SCREW
21	416120001	SET SCREW (M3x3 C)
23	270 R10083000	AUTO THREAD LEVER
24	68003556	AUTO THREADER
25	416152701	NEEDLE BAR SUPPORTER SPRING
26	416184601	SET SCREW (M3x4 C)
27	416466901	PRESSER BAR LIFTER LEVER
28	416162101	PRESSER BAR LIFTER LEVER SCREW WASHER
29	416121101	SET SCREW (M4x10 B)
30	416173401	PRESSER BAR
33	416151401	PRESSER BAR BRACKET
34	416151401	SET SCREW (M6x5 C)
35	416173501	PRESSER BAR SPRING
36	416495501	SHANK CPL.
37	416118401	SET SCREW (9/64x40x7.5)
38	416121001	SET SCREW (M4x5 C)

NOT AVAILABLE PARTS


1	416566901	NEEDLE BAR SUPPORTER
3	416642401	NEEDLE BAR SUPPORTER PIN
4	416227701	WASHER (6.2x12x0.5)
5	68015225	COLLAR
6	68013217	AUTO THREADER STOPPER
7	68013218	SET SCREW (M3x4)
12	416567001	NEEDLE BAR SWING RING
13	68014111	NEEDLE BAR SUPPORTER PLATE PIN
17		NEEDLE (#14)
18	68015231	AUTO THREADER SHAFT SPRING
19	68015230	THREADING SHAFT
20	416117201	PIN (2x14)
22	68015232	AUTO THREADED LEVER SPRING
31	68017578	TENSION LEVER LIFTER
32	416151601	TENSION LEVER LIFTER SPRING



Pos	Part No.	Description
<u>AVAILABLE PARTS</u>		
3	416116101	E-RING (ETW-4)
10	416116001	E-RING (ETW-3)
16	68013206	SET SCREW (M4x10 A)
21	416801101	NEEDLE BAR DRIVING ROD PIN

NOT AVAILABLE PARTS

1		
2		
4	416186201	WASHER (5.2x10x0.2)
5		
6		
7	416122701	SET SCREW (M4x0.7 L12)
8	68015308	NUT (M4x0.7)
9	68018778	ROD FOR 3337
11	416121201	SET SCREW (M4x6 B)
12		
13	416117501	PIN (3x10)
14		
15	416116301	E-RING (ETW-5)
17	68018779	ZIGZAG WIDTH CRANK FOR 3337
18		
19	68018780	ZIGZAG WIDTH CRANK PLATE FOR 3337
20	68018781	NEEDLE BAR DRIVING ROD FOR 3337
22	416116201	E-RING (ETW-4) FOR 3337




Pos	Part No.	Description
-----	----------	-------------

AVAILABLE PARTS

4	416116001	E-RING (ETW-3) FOR 3337
10	416226601	SET SCREW (M4x5 B) FOR 3337
11	416232001	BH POSITIONED PLATE FOR 3337
12	68003185	BH SELECT CRANK SHAFT FOR 3337
13	416231801	BH MOVEMENT CRANK FOR 3337
19	416116001	E-RING (ETW-3) FOR 3337
22	416195501	FEED REGULATOR GEAR
26	68003563	SHUTTLE HOOK CPL.
27	416144001	ROTARY HOOK PLATE (1)
28	416122901	SET SCREW (M4x6)
30	68003570	PRESS PLATE
31	412423701	THREAD CUTTER
32	68000175	BOBBIN
33	68003564	NEEDLE PLATE
34	68003565	NEEDLE PLATE SUPPORTER
35	68003567	NEEDLE PLATE COVER OPEN
36	68003568	NEEDLE PLATE COVER BRACKET
37	68003569	SET SCREW (M2x3.5 A)

NOT AVAILABLE PARTS

1	68018783	BH LEVER PLATE CPL. FOR 3337
2	416121201	SET SCREW (M4x6 B)
3	416728801	BH LEVER CRANK FOR 3337
5	416495301	BH LEVER FOR 3337
6	416116301	E-RING (ETW-5)
7	416729001	BH LEVER SPRING PLATE FOR 3337
8	416117001	PIN (1.6x5) FOR 3337
9	416231901	BH POSITIONED PLATE FOR 3337
14	270 004230056	SET SCREW (M3x5 B) FOR 3337
15	416728601	BH SELECT CRANK FOR 3337
16	416728201	BH SELECTOR PLATE FOR 3337
17	416600901	BH SLIDE PLATE FOR 3337
18	416185901	WASHER (4.2x9x0.5) FOR 3337
20	416728401	BH SELECTOR PLATE FOR 3337
21	416728501	BH CAM PLATE FOR 3337
23	416518401	SET SCREW (M3x8 A)
24	416601201	FEED REGULATOR DIAL SHAFT
25	416183901	PIN (2.5x16)
29	68015281	THREAD GUIDE STAND
38	416679801	SET SCREW (M2x3)
39	68012459	ROTARY HOOK PLATE(2) CPL.
40	68010961	NEEDLE PLATE COVER
#1	68004503	NEEDLE PLATE COVER COMPL.




Pos	Part No.	Description
-----	----------	-------------

AVAILABLE PARTS

2	416149701	FEED REGULATING
3	416122401	SET SCREW (M4x4 C)
11	416121101	SET SCREW (M4x10 B)
13	416116001	E-RING (ETW-3)
14	416149601	FEED REGULATING BLOCK
20	416192401	FEED ROCK CRANK
22	416195701	FEED ROCK CRANK SPRING
25	68003195	FEED DOG
27	416192301	FEED LIFTING ROCK CRANK
28	416121501	SET SCREW (M4x8 A)
30	68003066	FEED DOG SPRING
32	416683801	BELT ADJUSTING PLATE
33	416683901	BELT ADJUSTING PLATE PULLEY
34	416116101	E-RING (ETW-4)
35	416121601	SET SCREW (M4x12 B)

NOT AVAILABLE PARTS

#1	68017590	FEED ROCK SHAFT CPL.
1	416730901	FEED REGULATING SHAFT
4	416125601	WASHER (6.7x11.8x0.5)
5	416156901	FEED ROCK BUSHING
6	416124001	WASHER (6.7x12x1)
7	416116301	E-RING (ETW-5)
8	416601801	FEED REGULATING CRANK CPL.
9	270 E1A0493003	FEED CRANK
10	68015308	NUT (M4x0.7)
12	416116201	E-RING (ETW-4)
15	416122101	SET SCREW (M4x6 C)
16	416191901	FEED ROCK SHAFT
17	416192001	FEED DOG SUPPORTER
18	416192101	FEED DOG SHAFT
19	416549201	FEED ROCK FRAME SHAFT (2)
21	416192601	REGULATING BLOCK SHAFT
23	416186301	WASHER (5.2x12x1)
24	416192501	FEED ROCK SHAFT
26	270 004235016	SET SCREW (M3.5x8 A)
29	416185501	SET SCREW (M4x0.7 L9)
31	416192801	FEED CRANK SHAFT




Pos	Part No.	Description
-----	----------	-------------

AVAILABLE PARTS

2	68003196	FEED ROCK CAM
3	416122401	SET SCREW (M4x4 C)
5	416121001	SET SCREW (M4x5 C)
6	416191401	LOWER SHAFT SPRING
7	416191201	FEED LIFTING ROCK CAM
10	416141701	LOWER SHAFT BUSHING
14	270 H1A0463000	LOWER SHAFT BELT PULLEY
18	68013932	SHUTTLE HOOK COVER
19	416119501	SET SCREW (M3x12)
22	416143401	ROTARY HOOK SUPPORTER
23	416121501	SET SCREW (M4x8 A)
25	68003558	SHUTTLE HOOK HOLDER
27	416125901	ENDURE ATTRITION WASHER
28	416155601	BOBBIN SHAFT WASHER (2)
29	416145401	BOBBIN SHAFT
30	416155801	BOBBIN SHAFT OIL CLOTH
31	68013850	ENDURE ATTRITION WASHER

NOT AVAILABLE PARTS

1	416731301	LOWER SHAFT
4	68013976	LOWER SHAFT GEAR
8	416158801	LOWER SHAFT COLLAR
9	416125801	ENDURE ATTRITION WASHER
11	416186501	WASHER (8.2x12x0.5)
12	416116401	E-RING (ETW-6)
13	416191301	FEED LIFTING ROCK COM PIN
15	270 004250203	SET SCREW (M5x5 C)
16	416122101	SET SCREW (M4x6 C)
17	270 H1A0383006	ROTARY HOOK HOLDER
20	416191801	ROTARY HOOK HOLDER POSITIONED PLATE
21	416121201	SET SCREW (M4x6 B)
24	416679501	SET SCREW (M4x8)
26	416155701	BOBBIN SHAFT WASHER (3)




Pos	Part No.	Description
-----	----------	-------------

AVAILABLE PARTS

1	68003572	MOTOR FOR 120V / U.S.
2	416430001	MOTOR FOR 230V / E.U.
2	416528301	MOTOR FOR 240V / G.B.
3	416129401	CUSHION RUBBER
7	416428701	BELT WHEEL
8	416114501	MOTOR FEED REGULATOR COLLAR
9	416116001	E-RING (ETW-3)
14	416184701	RECEPTACLE
17	416183601	CONCERT INSULATION PLATE
19	416732501	LED HOLDER CPL. FOR 120V
19	416732601	LED HOLDER CPL. FOR 220V~240V
22	416803701	RECEPTACLE HOLDER COVER
24	416121701	SET SCREW (M4x15 B)
28	270 002V8E4003	FOOT CONTROLLER FOR 120V / U.S.
29	68001147	FOOT CONTROLLER FOR 230V / E.U.
29	416112701	FOOT CONTROLLER FOR 240V / G.B.

NOT AVAILABLE PARTS

4	416603701	MOTOR BRACKET
5	416528501	SET NUT (M4 t=5.5) FOR 120V
6	416521501	SET SCREW (M4x10.2) FOR 220V-240V
10	416124301	WASHER (5.4x10x0.9)
11	416126201	SPRING WASHER (5.2x9x1)
12	416224801	SET SCREW (M5x12)
13	416732301	RECEPTACLE HOLDER
15	68013230	WASHER
16	416528701	SET NUT (M3x4)
18	68013231	WASHER
20	416302901	NUT (M3 t=2.3)
21	416184901	SET SCREW (M3x20 B)
23	416119701	SET SCREW (M3x8 B)
25	416133001	END TERMED
26	416718201	SET SCREW (M3x5)
27	416113901	CORD CLIP
30	68013175	CONDENSER FOR 220V-240V
31	68013906	INSULATING SLICE FOR 120V



Pos	Part No.	Description
<u>AVAILABLE PARTS</u>		
1	416128701	ZIPPER FOOT (I)
2	416284501	BUTTON SEWING FOOT
3	68003699	ADJUSTABLE GUIDE FOOT FOR 3337 (USA)
4	416127701	SEAM RIPPER/ BRUSH
7	68003700	SPOOL HOLDER (LARGE)
8	68003701	SPOOL HOLDERS (SMALL)
9	68000175	BOBBIN
10	68000177	L-SCREWDRIVER
11	416223901	EMBROIDERY PLATE
12	68003702	SECOND SPOOL PIN
13	416127301	FELT PAD
14	416187101	ALL PURPOSE FOOT
15	68003698	BUTTONHOLE FOOT FOR 3337
17	68015375	SOFT COVER CPL.

NOT AVAILABLE PARTS

5	416497401	SEAM GUIDE
6		NEEDLE
16		