



SINGER®


C7200-C7205

C7220-C7225


C7250-C7255

Liste de pièces
Lista de Piezas
Parts List

A




Ref No	Part No	Part Name
1	68021902	FRONT COVER C7205
1	68021903	FRONT COVER C7200
1	68021904	FRONT COVER C7225
1	68021905	FRONT COVER C7220
1	68021908	FRONT COVER C7255
1	68021910	FRONT COVER C7250
2	68015139	BOBBIN WINDER THREAD GUIDE CPL.
3	68015142	ROW LINE
4	416804601	SPOOL PIN BASE
5	68016951	ARM THREAD GUIDE PLATE
6	68021911	FREE ARM COVER
7	68016985	FREE ARM BASE PLATE
8	68013144	PLATE (1)
9	68016954	SPEED ADJUSTMENT KNOB
10	416481401	SLIDE VOLUME KNOB CONNECTOR
11	68003819	SLIDE VOLUME
12	68016953	DROP FEED LEVER
13	68021912	OPERATION BUTTON
14	68021913	UP & DOWN FIXED POSITION SWITCH
15	68016955	THREAD GUIDE CPL.
16	68021914	LCD MAIN CIRCUIT BOARD
17	68021915	LCD PLASTIC COVER
18	68021947	MODE SELECT BUTTON
19	68021974	FUNCTION BUTTON
20	416554101	BOBBIN WINDER STOPPER
21	416804501	THREAD GUIDE
22	68016967	BACK COVER




Ref No	Part No	Part Name
1	68021981	FACE COVER
2	412423701	CUTTER
3	68021985	PATTERN PLATE COVER
4	68015178	BH LEVER BUTTON
5	68016988	TENSION SUPPORTER COVER C7205/C7200
6	68021988	TENSION SUPPORTER COVER C7225/C7220/C7255/C7250
7	68010960	THREAD TENSION DIAL
8	68021993	HAND WHEEL
9	270 V62033006	HANDLE BRACKET CPL.
10	68016991	HANDLE
11	68015189	SPACER
12		
13		
14		
15		
16		
17	68021997	BASE
18	68015214	FREE ARM FOOT
19	68012007	RUBBER CUSHION
20	68021999	PATTERN PLATE (1)
21	68022001	PATTERN PLATE (2)
#1	68017004	SEWING TABLE CPL.


C



Ref No	Part No	Part Name
1		
2		
3	416152201	GASKET
4	416685701	BELT
5	68003049	PHOTO SENSOR CPL.
6		
7		
8		
9		
10		
11	416680301	BELT
12		
13		
14		
15		
16		
17	416161701	BUSHING PRESSER
18		
19		
#1	68018716	UPPER SHAFT CPL.
#2	416484501	THREAD TAKE-UP LEVER CPL.




<u>Ref No</u>	<u>Part No</u>	<u>Part Name</u>
1	416173401	PRESSER BAR
2		
3		NEEDLE
4	68015224	PRESSER BAR SPRING
5	68017005	SHANK CPL.
6	416118401	SCREW
7	68013226	PRESSER BAR REGULATING SCREW
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20	68014111	NEEDLE BAR SUPPORTER PLATE PIN
21		
22		
#1	68022004	NEEDLE BAR SUPPORTER CPL.
#2	68015235	PRESSER BAR BRACKET CPL.




Ref No	Part No	Part Name
1	416568901	SOLENOID VALVE PLATE
2		
3		
4		
5	68016908	SOLENOID VALVE
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
#1	68022005	AUTO CUTTER CPL.
#2	416828801	MOVEMENT PLATE CRANK CPL.

F





Ref No	Part No	Part Name
1		
2		
3		
4		
5		
6		
7		
8		
9	416122901	SCREW
10		
11		
12		
13		
14	68012459	ROTARY HOOK PLATE (2) CPL.
15		
16	416569501	SUPPORTER
17		
18	68000175	BOBBIN
19		
20		
21		
22		
23		
24		
25	68016949	NEEDLE PLATE COVER
#1	68017006	NEEDLE PLATE CPL.
#2	68015290	BH LEVER PLATE CPL.
#3	68022007	INNER SHUTTLE HOOK CPL.


G



Ref No	Part No	Part Name
1		
2	416700601	BOBBIN WINDER CRANK CPL.
3	416684501	BOBBIN WINDER CRANK SPRING
4		
5		
6	68003659	PRESSER BAR LIFTER LEVER
7		
8		
9		
10	416123001	SCREW
11		
12	416151701	DIAL TENSION GUIDE SPRING TUBE
13		
14		
15		
16		
17		
18		
19		
20		
#1	416644001	BOBBIN WINDER CPL.
#2	68022008	DIAL TENSION CPL. C7205/C7200
#2	68022009	DIAL TENSION CPL. C7225/C7220/C7255/C7250
#3	68015299	CLAMP PLATE CPL.




<u>Ref No</u>	<u>Part No</u>	<u>Part Name</u>
1		
2		
3		
4		
5		
6		
7		
8		
9	416801101	NEEDLE BAR DRIVING ROD PIN
#1	68015306	ZIGZAG STEPPER MOTOR PLATE CPL.
#2	68015307	STEPPER SUPPORT PLATE CPL.




Ref No	Part No	Part Name
--------	---------	-----------

1		
2		
3		
4		
5		
6		
7		
8		
9	416498501	FEED DOG
10		
11		
12		
13		
14		
15	416356601	FEED REGULATING BLOCK
16		
17		
18		
19		
20	270 H1A0203000	FEED REGULATING SHAFT
21		
22		
23	68001430	SET WASHER
#1	68015314	FEED ROCK SHAFT CPL.
#2	416633601	BELT ADJUSTING PLATE CPL.
#3	68015316	FEED REGULATING CRANK CPL.
#4	SEE #3	FEED REGULATING CRANK CPL. (Replaced by 68015316)
#5	270 D3A1674000	FEED REGULATING CPL.


J



Ref No	Part No	Part Name
1	416156901	FEED ROCK BUSHING
2	270 H1A0463000	LOWER SHAFT BELT PULLEY
3	416141701	LOWER SHAFT BUSHING
4	416147301	BASE PLATE ADJUSTMENT SPRING
5	416154601	BASE PLATE ADJUSTMENT SCREW
6	416526001	RUBBER CUSHION
7	68003263	RUBBER CUSHION
8		
9		
10	416479801	SHUTTLE HOOK HOLDER
11		
12		
13		
14	416158801	LOWER SHAFT COLLAR
15		
16	416191201	FEED LIFTING ROCK CAM
17	416143401	ROTARY HOOK SUPPORTER
18	416191301	FEED LIFTING ROCK COM PIN
19	416191401	LOWER SHAFT SPRING
20		
21		
22		
23		
24		
25	270 H1A0133000	LOWER SHAFT
#1	68017008	ROTARY HOOK HOLDER CPL.
#2	68015319	ROTARY HOOK SUPPORTER CPL.
#3	68015320	FEED ROCK CAM CPL.
#4	416197101	LOWER SHAFT GEAR CPL.



Ref No	Part No	Part Name
1		
2		
3		
4		
5		
6		
7	68015376	FRAME OF MAIN CIRCUIT BOARD
8	416687301	GROUND CONNECTION
9	68021909	MAIN CIRCUIT BOARD
10		
11		
12		
13		
14		
15	416113901	CORD CLIP
16	416115501	CORD CLIP
17	412157903	POWER CORD CPL. 120V / US
17	412157801	POWER CORD CPL. 230V / EU
18		
19		
#1	68021916	HF TRANSFORMER BOX CPL. 120V / US
#1	68021917	HF TRANSFORMER BOX CPL. 230V / EU.
#2	68017016	RECEPTACLE HOLDER CPL. 120V
#2	68017015	RECEPTACLE HOLDER CPL. 220V~240V
#3	68003052	DC MOTOR CPL.
#4	68011738	FOOT CONTROLLER & BAG CPL.



Ref No	Part No	Part Name
1	68017019	ALL PURPOSE FOOT
2	416128701	ZIPPER FOOT
3	416437101	BLIND HEMMING FOOT
4	416437201	FANCY STITCHES FOOT
5	416284501	BUTTON SEWING FOOT
6	416494101	OPEN TOE APPLIQUE FOOT
7	270 006813008	CORDING FOOT
8	68017017	BUTTONHOLE FOOT CPL.
9	68000175	BOBBIN
10	68003700	SPOOL HOLDER (LARGE)
11	68003701	SPOOL HOLDER (SMALL)
12	416127301	SPOOL PIN FELT
13	68003702	SPOOL PIN
14	68000177	L-SCREWDRIVER
15	416127701	BRUSH & SEAM RIPPER CPL.
16		NEEDLE
17	68017018	SEAM GUIDE / QUILTING BAR
18	68017069	SOFT COVER
#1	68021918	ACCESSORY CPL. C7205/C7200/C7225/C7220
#1	68021919	ACCESSORY CPL. C7255/C7250